

Instructions Match Patch Pro Pin Hole Grout Powder

Surface Conditions: Compatible with wet or dry Concrete Polish procedures.

www.matchpatchpro.com

Packaging: 50 pound pail that will do 5,000 – 7,000 sq ft

Color: White

Cure time: 2 Hours

1. Wet clean floor after #100 grit cut exposing and cleaning all imperfection.



2. Liberally Broadcast grout onto floor. Only enough to fill imperfections.



3. Spread dry grout evenly with broom.



4. Use STI Grout pans on grinder.
<http://www.substratetechnology.com/tools/tools-terrazzo/eg-grout-pans-detail>



5. Spraying 20% Latex - 80% water in front of grinder with grout pans attached, drive in wet grout powder. Crosshatch if floor is not flat.



6. Let Grout dry and spray densifier just enough to wet the dry grout.



7. Let completely dry (about 1 hour) and move forward with polishing process. Most use #100 resins to cut off excess dried grout.



1. Grout becomes harder with every hour after the densifier has dried. Do not wait more than 2 hours to cut off excess or it will become too hard.
2. Technical help, call Dave Moore 941-408-5999
Instruction Video:
www.youtube.com/watch?v=ITRkId6ZiGw
3. **Difference Between Grinder dirt and MPP:**
www.youtube.com/watch?v=t_LCIZmMggM