

# Match Patch Pro Dry Grout Instructions 2019

**Surface Conditions:** Compatible with wet or dry Concrete Polish procedures. [www.matchpatchpro.com](http://www.matchpatchpro.com)

**Packaging:** One gallon pail that will do 1,200-1,500 sq ft **Color:** White **Cure time:** 2 Hours dry cut, 12 hours wet.

1. Wet clean floor after SCP #299 or #100 grit other systems. Wet clean entire floor, let surface visibly dry.



2. Liberally Broadcast grout onto floor. Only enough to fill imperfections.



3. Spread dry grout evenly with broom.



4. Use SCP Grout pans on grinder. Video Instruction



5. Spraying 600-700 square feet per gallon, 50% SCP Sealer Step 3 with 50% water in front of grinder with grout pans attached, drive in wet grout powder. Crosshatch if floor is not flat. Slowest speed on grinder and move machine at walking speed.



6. Allow grout dry and spray SCP Step 2 Hardener at 400-600 square feet per gallon. Other systems call in for recommendation.



7. Allow to cure 12 hours for wet cut and 2 hours for dry cut.



8. Using SCP #400 semi metals wet, remove excess grout. Dry cut or other systems use #100 hybrid tooling.

9. Technical assistance: Dave Moore 941-408-5999

10. If cutting off wet, allow 12-hour cure.

11. Pans create gray color. Do not sit in one place too long or will burn floor.

Match Patch Pro